



LITE

PRO



## INSTRUCTIONS SETUP



### Notes on safe use of door operators

*There is a risk of serious or fatal injury if the ismartgate device is not used correctly.*

- Ø Keep children away from the ismartgate and the user interface.
- Ø Do not drive through the door until it has fully opened.
- Ø Observe all warnings and safety information in the installation and operating manual for the operator.

### Notes on safe operation of the ismartgate device.

The ismartgate device may only be used on the operator in combination with a photocell.

# CONTENTS

Legal information	Page 3	Ismartgate Reset	Page 14
Intended use	Page 3	Initial operation IOS	Page 17
EU Declaration of Conformity	Page 3	Initial operation Android	Page 36
Technical Information	Page 4	Garage installation	Page 54
Functional description.	Page 4	Garage Motor installation	Page 56
Technical Data	Page 4	Garage Button installation	Page 57
Interfaces and LEDs for the PRO	Page 5	Gate installation	Page 59
Interfaces and LEDs for the LITE	Page 6	Wireless Gate kit sensor (GWS)	Page 60
What's in the Box	Page 7	Wireless Garage kit sensor (TWS)	Page 64
Considerations for installation	Page 11	Wired sensor (WDS)	Page 67
Download the App	Page 13		

# LEGAL INFORMATION

## INTENDED USE

The ismartgate may be used in combination with any compatible garage door or gate operator.

With an established network connection, the door can be opened and closed, the current door status and the door status by calendar day queried, settings can be made and administrators and users managed via the user interface (Apple, Android or computer browser).

In addition, with the corresponding accessories, a video live stream of the door system can be transmitted to the user interface.

Any use above and beyond this is deemed to be improper use and is therefore not permissible. Improper use will render all claims under warranty null and void.

### Useful Links:

#### Website:

<https://www.ismartgate.com/>

#### Manual:

<https://setup.ismartgate.com/>

#### Compatibility Checker:

<https://ismartgate.com/compatibility-checker/>



### EU Declaration of Conformity

<b>Manufacturer:</b>	<b>Name:</b>	REMSOL EUROPE S.L.
	<b>Address:</b>	Fructuós Gelabert, 2 (Office 4-2) Sant Joan Despí, 08970, Barcelona, SPAIN
<b>Equipment:</b>	<b>Name:</b>	ismartgate Lite / PRO
	<b>Model Number:</b>	ISG-02WXXYYY (00<=NA,EU,UK,AU, YYY=102,103,202,203)
	<b>Software:</b>	v1.4.9
	<b>Product Type:</b>	Smart Garage Door Opener Accessory
	<b>*Supplied Accessories:</b>	Power adapter

We, **REMSOL EUROPE S.L.**, declare under our sole responsibility that the above referenced product complies with the following:

<b>Directives:</b>	<b>2014/53/EU</b>	
	<b>2009/125/EC</b>	
	<b>2011/65/EU</b>	
<b>Article 3.1a:</b>	<b>Safety and Health</b>	
	EN 60950-1:2008+A1:2010/A11:2009+A12:2011+A2:2013	
	EN 62479:2010	
<b>Article 3.1.b:</b>	<b>EMC</b>	
	EN 301 489-1 V2.2.0	
	EN 301 489-17 V3.2.0	
<b>Article 3.2:</b>	<b>Frequency:</b>	<b>Power:</b>
	2.400 - 2.4835 GHz	<100mW
		<b>RF Spectrum Efficiency</b>
		EN 300 328 v2.1.1
<b>Additional Compliance:</b>	<b>RoHS:</b>	EN50581:2012

**Signed for and on behalf of:** **REMSOL EUROPE S.L.**

**Place:** Barcelona **Date:** 15 May 2019

<b>Name:</b>	<b>Function:</b>	<b>Signature:</b>
Joan Llopert Masana	CTO	

## FCC / IC Statement (USA / Canada)

### Item No.: ISG-TWS & ISG-GWS / 2401.0

This device complies with FCC rules part 15. The operation of this device is subject to the following conditions:

- 1) This device may cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation!

# TECHNICAL INFORMATION

## FUNCTIONAL DESCRIPTION

The ismartgate serves as an interface between end devices such as a PC (browser), Tablet or Smartphone (Android and iOS) and any compatible garage door or gate operator. Up to three (3) operators can connect to one (1) ismartgate Pro and one (1) door operator to one (1) ismartgate LITE. The ismartgate devices are then connected to a network using Wi-Fi or LAN.

This enables communication with the operator via a graphical user interface. Among other things, the door status can be queried and access rights assigned to users\*. A web cam can be integrated via a plug-in and the door status transmitted per live stream to the user interface.

\*10 users free of charge, while a paid plug-in allows you to add 100 or an unlimited number of users.

The connection can be established in two ways:

### Client Mode (Standard):

The ismartgate is integrated into the home network via Wi-Fi. The end device must have a data connection with adequate bandwidth. This allows you to access and operate the user interface via the app or a browser from any location where the data connection is available.

### Access Point Mode (Stand-alone):

The ismartgate functions as a Wi-Fi access point if no home network is available. A router is not required. The device can not switch automatically to the access point mode from Client Mode.

Access to user interface is only possible within the Wi-Fi radius. Remote Control is not possible.


## Technical data

Power Supply input	
Rated voltage	100 - 240 V
Rated Frequency	50 / 60 Hz
Power Supply output	
Rated voltage	5V / DC
Rated current	2 A
Ismartgate Input	
Rated voltage	5V / DC
Rated current	2 A
Dimensions (without power supply unit)	110 x 110 x 27 mm
Wi-Fi standards	2.4 GHz / IEEE 802.11b/g/n

PRO

# ismartgate PRO


## INTERFACES & LEDS



LITE

# ismartgate LITE

## INTERFACES & LEDS



# WHAT'S IN THE BOX

## ISMARTGATE PRO GARAGE KIT

**PRO**

**ismartgate PRO**  
**Garage Kit**



ismartgate PRO



Wireless Sensor  
(ISG-TWS)




3x Connection Cables



LR1/Type-N 1.5V  
Batteries



Power Supply



Quick Start Guide

# WHAT'S IN THE BOX

## ISMARTGATE LITE GARAGE KIT

**LITE**

**ismartgate LITE**  
**Garage Kit**



ismartgate LITE



Wireless Sensor  
(ISG-TWS)




1x Connection Cables



LR1/Type-N 1.5V  
Batteries



Power Supply



Quick Start Guide

# WHAT'S IN THE BOX

## ISMARTGATE PRO GATE KIT

PRO



ismartgate PRO  
Gate Kit



ismartgate PRO



Wireless Sensor  
(ISG-GWS)




3x Connection Cables



LR1/Type-N 1.5V  
Batteries



Power Supply



Quick Start Guide

# WHAT'S IN THE BOX

## ISMARTGATE LITE GATE KIT

LITE



**ismartgate LITE**  
**Gate Kit**




ismartgate LITE



Power Supply



Wireless Sensor  
(ISG-GWS)



Quick Start Guide



1x Connection Cables




LR1/Type-N 1.5V  
Batteries

# CONSIDERATIONS FOR INSTALLATION

## SETUP ENVIRONMENT

We recommend programming the ismartgate in a room close to home main Wi-Fi router, in a clean surface like a desk. It is also recommended to have both a Smartphone and PC. Finally make sure you have a power outlet close by, where to power on the ismartgate device.

- 1. PC (Laptop):** Use your laptop to follow this manual instructions.
- 2. Smartphone:** To program ismartgate from the app.
- 3. Router:** To make sure there is a strong Wi-Fi (2.4GHz Network) during programming.
- 4. Power Outlet:** To power on your ismartgate device.
- 5. Desk:** Flat surface to program the ismartgate device.




# CONSIDERATIONS FOR INSTALLATION

## ISMARTGATE PLACEMENT

Make sure ismartgate is placed in the area with 50% or more Wi-Fi signal strength.

Wi-Fi must be 2,4Ghz-802.11 b/g/n  
(NOT 5Ghz - 802.11 ac)

Device can be placed next to  
Garage Door opener or Wall  
Mounted Push Button



# PROGRAMMING ISMARTGATE

Download APP (ismartgate Access)



Download the “ismartgate Access” APP for your iPhone/iPad or for your Android phone.




# RESETTING ISMARTGATE

THE DEVICE MUST BE POWERED ON

1

With the help of a paperclip, press the RESET button for about 10 seconds.



# RESETTING ISMARTGATE

THE DEVICE MUST BE POWERED ON

2

To check RESET has been successful, turn the ismartgate device to the front and check that “Connection & Status” lights are off.



# RESETTING ISMARTGATE

THE DEVICE MUST BE POWERED ON


3

Wait 2 minutes until you see blinking:

- Status green light
- Power red light
- Wi-Fi blue light

Then re-program the ismartgate.

If RESET is successful, re-program the ismartgate device, go to page [36](#) for Android, and [17](#) for iOS





# PROGRAMMING ISMARTGATE (iOS)


## ISMARTGATE ACCESS APP SETUP



On your phone, look for the logo of the ismartgate app and click on it to open the app



Wait for the introductory screen to go away.



Press "No, Thanks"



# PROGRAMMING ISMARTGATE (iOS)


## ISMARTGATE ACCESS APP SETUP



Press "Start Configuration"



Power up the iSmartgate. Afterwards, press "Model Pro/Lite"



Wait 2 minutes until a sound comes on (only in the PRO version). And Select "Next"



# PROGRAMMING ISMARTGATE (iOS)

PLEASE LOOK CAREFULLY AT THE NETWORK LIGHT OF THE ISMARTGATE



Connection light blinks **blue**

***You only have 15 minutes to start the configuration, if the light starts blinking red, please unplug the device and plug it in again.***

[Please go to page 20](#)



Connection light blinks **green**

[Please go to page 26](#)



Connection light blinks **red**

[Please go to page 14](#)



# PROGRAMMING ISMARTGATE (iOS)

## HOME APP SETUP



Press "No"




1. You should now leave the ismartgate app
2. Go to the "Home" app and follow the steps from this animation above.



# PROGRAMMING ISMARTGATE (iOS)

## HOME APP SETUP



Go to your main screen and open the "Home" app



Select the "Add Accessory" option.




# PROGRAMMING ISMARTGATE (iOS)


## HOME APP SETUP



The QR code is at the back of the ismartgate device



Scan the QR code. Please make sure your phone is connected to a 2.4GHz network, the one you want the ismartgate to connect to.




If the connection is successful, press the "Add to Home" button.



# PROGRAMMING ISMARTGATE (iOS)


## HOME APP SETUP



Press the "Allow" button.



Now your ismartgate is connecting to your Wi-Fi network. Wait 30s seconds




If after 30 seconds, the device Wi-Fi light is still in red. Reset the ismartgate and try again. To reset go to Page 14.




# PROGRAMMING ISMARTGATE (iOS)


## HOME APP SETUP




1. Assign a "room" for the device (ie. garage).
2. Press the "Continue" button.



Press the "Continue" button.



Press the "Continue" button.




Press the "Continue" button.




# PROGRAMMING ISMARTGATE (iOS)


## HOME APP SETUP




1. Assign a "room" for the garage Door (ie. Garage).
2. Press the "Continue" button.



Press the "Continue" button.



Press the "Done" button.



On the Home App, you should see the doors available, but you need to finish the configuration in the ismartgate app in order to use them.



# PROGRAMMING ISMARTGATE (iOS)

## JOIN CONNECTED ISMARTGATE



Connection light blinks **green**



Go to phone main screen and open the iSmartgate app again.



You will be back to the same step you were before "Wi-Fi Connection".

Make sure that your iPhone is connected to the same Wi-Fi as the iSmartgate.

Click "Next".



The app will now look for devices to connect. Once found, you will see an icon of your iSmartgate device. Click on it.

If the "iSmartgate Access App" doesn't find your "iSmartgate device", follow these steps:

- 1) Go to your iPhone main settings
- 2) Go to Privacy > Local Network
- 3) Be sure that the "iSmartgate" has this permission enabled.




# PROGRAMMING ISMARTGATE (iOS)

## ISMARTGATE ACCESS APP SETUP



Press "Next", after choosing your language



Define how many doors you want to control:

1. Start "Enabling" DOOR 1
2. Scroll down.



Fill the following fields:

- Door mode: Garage / Gate
- Door Images: Default / Custom (you can upload pictures of your garage door open/closed)
- Door name

4. Sensor type. Check carefully!



5. Sensor ID.  
Then Scroll down



# PROGRAMMING ISMARTGATE (iOS)

## HOMEKIT ONLY or ISMARTGATE + HOMEKIT CHOICE



**Full Setup**  
(RECOMMENDED)

You will enjoy all ismartgate features:

- Remote Access
- Apple HomeKit
- Video recording & Streaming
- User Management
- Home Integration with Google Home / Amazon Alexa
- Automatic Open/Close with IFTTT

ISMARTGATE + HOMEKIT

[Please go to Page 29](#)



HomeKit

**HomeKit**  
(ONLY)

Your ismartgate can **only be used with Apple's Home app**.\*  
You may **NOT be able** to enjoy the following features:

- User Management
- Video Monitoring of garage
- Integration with other Smart Home platforms
- Temperature alerts
- **FIRMWARE UPDATES**

\*To remotely control your ismartgate with Siri or Apple Home app you may need an Apple TV or Apple HomePod connected to the same Wi-Fi network than ismartgate. If not, the ismartgate is only controllable locally with Siri and Apple's Home app.

HOMEKIT

[Please go to Page 33](#)





# PROGRAMMING ISMARTGATE (iOS)

## HOME + ISMARTGATE ACCESS APP SETUP

INSTRUCTIONS SETUP

LITE

PRO



A warning will pop-up. Please read carefully.

Press "Continue Setup"



# PROGRAMMING ISMARTGATE (iOS)

## HOME + ISMARTGATE ACCESS APP SETUP



INSTRUCTIONS SETUP


LITE

PRO




Define your settings as the “admin” of the device:

1. Write down your UDI in a safe place.
2. Scroll down.



Fill in the fields:

1. New Password: Define your ismartgate account Password.
2. Retype new Password: for security reasons.
3. Contact Name: Put your name.
4. Email: Put your email address.
5. Introduce the Google security code to activate the door with Google Assistant (mandatory). Write it down in a secure location. Click “Next”



1. Define the name of the ismartgate device itself (not the doors). This name can be changed later.

2. Press “Next”.



# PROGRAMMING ISMARTGATE (iOS)

## HOME + ISMARTGATE ACCESS APP SETUP



INSTRUCTIONS SETUP


LITE

PRO




Remote access will allow you to operate your iSmartgate device from anywhere with a Smartphone, Tablet, PC and Apple Watch.

1. Read Terms & Conditions.
2. Scroll down.



1. Accept Terms & Conditions to enable the Remote Access.
2. Press "Next".

Please, keep in mind that the Remote Access feature takes 10 minutes to be available to use.



The device will now reboot. Wait for approx. 2 minutes. In the meantime, please make sure you are connected to same WiFi network as the iSmartgate device.




# PROGRAMMING ISMARTGATE (iOS)

## HOME + ISMARTGATE ACCESS APP SETUP

INSTRUCTIONS SETUP

LITE

PRO



If you see the above screen, your ismartgate is successfully connected to your WiFi network.

[Please go to Page 54](#)



If you see the above picture, it means the ismartgate is not connecting to your smartphone.

[Please go to Page 14](#)




# PROGRAMMING ISMARTGATE (iOS)


## HOMEKIT ONLY APP SETUP



HomeKit



A warning will pop-up. Please read carefully.



Press "Only Homekit"



# PROGRAMMING ISMARTGATE (iOS)


## HOMEKIT ONLY APP SETUP



HomeKit



Close the "ismartgate" app.



Go to "iPhone main screen" on iPhone and open the "Home" app.




Your ismartgate device is already set up on your Apple Home App. You can control your garage from this app and using voice commands with Siri.




# PROGRAMMING ISMARTGATE (Android)


## ANDROID APP SETUP



On your phone, look for the logo of the ismartgate app and click on it to open the app



Wait for the introductory screen to go away.



Press "No, Thanks"




# PROGRAMMING ISMARTGATE (Android)


## ANDROID APP SETUP



Press "Start Configuration"



Power up the iSmartGate. Afterwards, press "Model Pro/Lite"



Wait 2 minutes until a sound comes on (only in the PRO version). And Select "Next"



# PROGRAMMING ISMARTGATE (Android)

PLEASE LOOK CAREFULLY AT THE NETWORK LIGHT OF THE ISMARTGATE



Connection light blinks **blue**

**You only have 15 minutes to start the configuration, if the light starts blinking red, please unplug the device and plug it in again.**

[Please go to page 38](#)



Connection light blinks **green**

[Please go to page 52](#)




Connection light blinks **red**

[Please go to page 14](#)



# PROGRAMMING ISMARTGATE (Android)

## ANDROID APP SETUP



You can see the instructions to connect to the iSmartgate generated network from the iSmartgate app



Go to the Wi-Fi settings on your phone.




# PROGRAMMING ISMARTGATE (Android)

## ANDROID APP SETUP



Select "Wi-Fi" (aka. WLAN) Settings.



Enable "Wi-Fi" settings on your phone if you haven't done so yet.



# PROGRAMMING ISMARTGATE (Android)

## ANDROID APP SETUP



From the list of available Wi-Fi networks, select the one starting with "iSG-XXXXXXXXXX".





If you don't find the "iSG-xxxxxxx" network, please check the Wi-Fi Connection lights:



The Wi-Fi light blinks **RED** and **GREEN**.  
Please Reset the device.



The Wi-Fi light blinks another color.  
Please send us an email at:  
[support@ismartgate.com](mailto:support@ismartgate.com)




# PROGRAMMING ISMARTGATE (Android)

## ANDROID APP SETUP



A message will “pop-up” indicating the “ISG-XXXXXXXXXX” network does NOT have internet access. Please stay connected to that network.




You can check you successfully connected to the “ISG-XXXXXXXXXX” network if you see a message saying “Connected” beneath the network name.




# PROGRAMMING ISMARTGATE (Android)

## ANDROID APP SETUP



Open the "ismartgate" app again.



You will be back to the same step you were before connecting to "iG-XXXXXXXXXX" network. Press "Next".



The app will now look for devices to connect. Once found, you will see an icon of your iSmartgate device. Click on it.



If you don't find the device, press "Refresh" button. If it is still not there, please check the Wi-Fi lights: go to page 37




# PROGRAMMING ISMARTGATE (Android)

## ANDROID APP SETUP



Press "Start Configuration"



Define how many doors you want to control:


1. Start "Enabling" DOOR 1
2. Scroll down.



Fill the following fields:

- Door mode: Garage / Gate  
Door Images: Default / Custom (you can upload pictures of your garage door open/closed)  
Door name

4. Sensor type. Check carefully!




5. Sensor ID.  
Then Scroll down



# PROGRAMMING ISMARTGATE (Android)


## ANDROID APP SETUP



After scrolling down to the bottom, press "Next".



**NOTE:** Do not forget to enable the second or third door in case you need them.



Define your settings as the "admin" of the device:

1. Write down your UDI in a safe place
2. Scroll down.



Fill in the fields:


Choose any Google security code to activate the door with Google Assistant (mandatory). Write it down in a secure location. This code did NOT exist before this moment.

Click "Next"




# PROGRAMMING ISMARTGATE (Android)

## ANDROID APP SETUP



Fill in the fields:


1. Introduce your preferred name for ismartgate device (it can be changed later)
  2. Wi-Fi Mode: Client Mode (to connect to your home Wi-Fi network) / Stand Alone (to have ismartgate create its own Wi-Fi network)
  3. Configuration mode: Automatic (recommended) / Manual (to put the information from your Wi-Fi network manually)
- Scroll down



**NOTE: DO NOT HIT NEXT YET.**

Press scan Wi-Fi networks if you chose the "Automatic" (recommended) option.

Wait for the list of available Wi-Fi networks to display.



On the list of available "Wi-Fi" networks, select your home Wi-Fi network (the network where you want your ismartgate device to connect). Please know that it needs to be a 2.4GHz network.



We strongly recommend to select only the Wi-Fi with "green" color. If your Wifi appears in "red", please try to improve its signal.



# PROGRAMMING ISMARTGATE (Android)


## ANDROID APP SETUP



1. Once the Wi-Fi network is selected, put the password of your "Wi-Fi" network.
2. Press "Next"



- Remote access will allow you to operate your iSmartgate device from anywhere with a Smartphone, Tablet, PC and Apple Watch:
1. Read Terms & Conditions
  2. Scroll down.



1. Accept Terms & Conditions to enable the Remote Access.
2. Press "Next".




Please, keep in mind that the Remote Access feature takes 10 minutes to be available to use.



# PROGRAMMING ISMARTGATE (Android)


## ANDROID APP SETUP



Scroll down and check the color of your ismartgate device connection light



1. Read the 4 possible options for the device "Connection Status".
2. Press "Finish"




The device will now reboot. Wait for approx. 2 minutes. In the meantime, please make sure you are connected to same Wi-Fi network as the ismartgate device




# PROGRAMMING ISMARTGATE (Android)


## ANDROID APP SETUP



The device is successfully connected to the selected Wi-Fi network and has an internet connection.




The device is successfully connected to the selected Wi-Fi network but does not have an internet connection.



The device has been setup in Access Point mode (Standalone)



Every 10 minutes the device will check automatically if there is an internet connection



The device can't connect to the selected Wi-Fi network (Wi-Fi password might be incorrect) or the Wi-Fi signal is not strong enough

To reset the device  
[go to page 14](#)

[Go to page 49](#)



# PROGRAMMING ISMARTGATE (Android)


## ANDROID APP SETUP



Go to Settings on your phone.



Select "Wi-Fi" (aka. WLAN) Settings.




Enable "Wi-Fi" settings on your phone if you haven't done so yet.




# PROGRAMMING ISMARTGATE (Android)

## ANDROID APP SETUP



From the list of available Wi-Fi networks, select the one where you already connected your ismartgate device.




Check that you are successfully connected to that network. For that, look for the "Connected" message under the network name.




# PROGRAMMING ISMARTGATE (Android)

## ANDROID APP SETUP



If you see the above screen, your ismartgate is successfully connected to your WiFi network.

[Please go to Page 54](#)



If you see the above picture, it means the ismartgate is not connecting to your smartphone.

[Please go to Page 14](#)



# PROGRAMMING ISMARTGATE (Android)

## JOIN AN ALREADY CONFIGURED ISMARTGATE



Contact to your iSmartgate Administrator to ask for:

- 1) UDI
- 2) Login (default is admin)
- 3) Password (default is blank)


Once you have these credentials, press "Done".

Wait for your phone to connect with your iSmartgate.




# PROGRAMMING ISMARTGATE (Android)

## JOIN AN ALREADY CONFIGURED ISMARTGATE



If you see the above screen, your ismartgate is successfully connected to your WiFi network.

[Please go to Page 54](#)



If you see the above picture, it means the ismartgate is not connecting to your smartphone.

[Please go to Page 14](#)

# INSTALLING ISMARTGATE

## GARAGE INSTALLATION



### GARAGE DOOR OPENER

We recommend wiring the ismartgate directly to your Garage Door Opener if you don't have push buttons or if power outlets aren't close to push buttons.

[Go to Page 55](#)



### GARAGE WALL PUSH BUTTON

We recommend wiring the ismartgate to your wall mounted push button if you have power outlets nearby (less than 30 inches / 1 meter)

[Go to Page 57](#)

# INSTALLING ISMARTGATE

## GARAGE MOTOR INSTALLATION



x1



x2



x3



Installation for 1 Door



Installation for 2 Doors




Installation for 3 Doors

# INSTALLING ISMARTGATE


## GARAGE MOTOR PLACEMENT AND INSTALLATION



UNDER THE MOTOR



ON TOP OF THE MOTOR



ON THE SIDE OF THE MOTOR



To know how to connect the ismartgate to your specific motor, please go to the Compatibility Checker: <https://ismartgate.com/compatibility-checker/>

# INSTALLING ISMARTGATE

## PUSH BUTTON INSTALLATION



Installation for 1 Door




Installation for 2 Doors




Installation for 3 Doors

# INSTALLING ISMARTGATE

## PUSH BUTTON INSTALLATION




Unscrew the push button from the wall.



Unscrew (not completely) the 2 screws from your opener.



Wire the ismartgate outputs to the screws on your push button. Polarity does NOT matter. Then screw again.



Screw your push button back.

# INSTALLING ISMARTGATE

## GATE MOTOR INSTALLATION




if your ismartgate does not fit inside the gate operator / control box, we strongly recommend to put the ismartgate device inside an ismartgate IP waterproof enclosure

To know how to connect the ismartgate to your specific motor, please go to the Compatibility Checker: <https://ismartgate.com/compatibility-checker/>

# ISMARTGATE WIRELESS SENSORS

## ISMARTGATE WIRELESS MAGNETIC SENSOR (GWS) INCLUDED IN THE GATE KIT



**Transmitter:** 2401 Mhz

**Type:** Magnet

**temperature indicator:** included

**Range:** 50 ft

**Operating temperature:** -25°C / 70°C

**Batteries:** 2x Type-N (1.5V)



**Life span:** 18 months

**Waterproof:** Yes

# ISMARTGATE WIRELESS SENSORS

## ISMARTGATE WIRELESS MAGNETIC SENSOR (GWS) INCLUDED IN THE GATE KIT


Test the sensor:  
move the sensor as the  
images above and see if the  
ismartgate status light  
(yellow) blinks rapidly



# INSTALLING ISMARTGATE SENSORS

## COMPATIBLE GATES WITH THE GWS SENSOR


### FOLDING



SENSOR PLACEMENT:




### SLIDING



SENSOR PLACEMENT:



### SWING



SENSOR PLACEMENT:



# INSTALLING ISMARTGATE SENSORS

## COMPATIBLE GARAGE DOORS WITH THE GWS SENSOR


### ROLLER



#### SENSOR PLACEMENT:



### SIDE-SECTIONAL




#### SENSOR PLACEMENT:



### SWING




#### SENSOR PLACEMENT:



# ISMARTGATE WIRELESS SENSORS

ISMARTGATE WIRELESS TILT SENSOR (TWS) INCLUDED IN THE GARAGE KIT



**Transmitter:** 2401 Mhz

**Type:** Gravity Sensor  
temperature indicator: included

**Range:** 50 ft

**Operating temperature:** -25°C / 70°C

**Batteries:** 2x Type-N (1.5V)



**Life span:** 18 months

**Waterproof:** Yes

# ISMARTGATE WIRELESS SENSORS

## ISMARTGATE WIRELESS TILT SENSOR (TWS) INCLUDED IN THE GARAGE KIT

**Test the sensor:**  
move the sensor as the  
images above and see  
if the ismartgate  
status light (yellow)  
blinks rapidly



# INSTALLING ISMARTGATE SENSORS

## COMPATIBLE GARAGE DOORS WITH THE TWS SENSOR


### SECTIONAL




SENSOR PLACEMENT:



### UP-AND-OVER



SENSOR PLACEMENT:




# INSTALLING ISMARTGATE SENSORS

ISMARTGATE WIRED MAGNETIC SENSOR (WDS) INCLUDED IN THE MINI WIRED KIT




**A**

Place this part on the Gate / Garage Door



**B**

Place this part on the wall






COMPATIBLE ONLY WITH

ismartgate **PRO** **mini**

**Output:** Normally Open (NO)  
**Max. switching voltage:** 100V dc  
**Max. contact rating:** 10W  
**Max. switching current:** 0.5A  
**Max. carrying current:** 1.0A  
**Temperature:** -20°C / 80°C  
**Material:** ABS  
**Contact life:** 1x10<sup>8</sup>  
**Waterproof:** Yes - IP65  
**Cable gauge:** 24# AWG (2 cables)

Sensor connection instructions for the ismartgate PRO:




# INSTALLING ISMARTGATE SENSORS

## ISMARTGATE WIRED MAGNETIC SENSOR PLACEMENT ON A ROLLER GARAGE DOOR

### A) Installation on a Roller Door

Attach your magnetic wired sensors to your roller door as per drawing below.




PLACE THE SENSOR ON THE LOWER PART OF YOUR ROLLER DOOR.

# INSTALLING ISMARTGATE SENSORS


## ISMARTGATE WIRED MAGNETIC SENSOR PLACEMENT ON A SECTIONAL GARAGE DOOR

### B) Installation on a Sectional Door

Attach your magnetic wired sensors to your Sectional Door as per drawing below.



PLACE THE SENSOR IN THE SECTION AT THE BOTTOM OF YOUR DOOR.




MAKE SURE THE GAP BETWEEN  
PART B AND PART A IS LESS THAN  
**1.25 INCH (3 CM).**

# INSTALLING ISMARTGATE SENSORS

## ISMARTGATE WIRED MAGNETIC SENSOR PLACEMENT ON A SLIDING GATE

### C) Installation on a Sliding Gate

Attach your magnetic wired sensors to your sliding gate as per drawing below.



PLACE THE SENSOR IN THE MIDDLE PART OF YOUR SLIDING GATE.


MAKE SURE THE GAP BETWEEN  
PART B AND PART A IS LESS THAN  
**1.25 INCH (3 CM).**

# INSTALLING ISMARTGATE SENSORS

## ISMARTGATE WIRED MAGNETIC SENSOR PLACEMENT ON A SWING GATE

### D) Installation on a Swing Gate

Attach your magnetic wired sensor to your swing gate as per drawing below.



PLACE THE SENSOR IN THE MIDDLE PART OF YOUR SLIDING GATE.

MAKE SURE THE GAP BETWEEN  
PART B AND PART A IS LESS THAN  
**1.25 INCH (3 CM).**



---

**CONGRATULATIONS!**

Your installation is done.

[www.ismartgate.com](http://www.ismartgate.com)